




Going GREEN  
We no longer print Quicks start Guides.  
Quick start Guides (PDF) are available on our website:

[www.eliteacoustics.com](http://www.eliteacoustics.com)

## A1-4 (A1BR8) Battery replacement

BATTERY TYPE: SLA 12V 7A to 9A

Product Dimensions: 5.9 x 3.7 x 2.6 inches — any SLA battery with this size will work. 12V 7AH, 8AH or 9AH



## Information on removal of the battery

- 1) Remove the Top 2 screws and 9 Rear BLACK screws.
- 2) Slide the Chassis assembly, discount the Battery Connections.
- 3) Carefully remove the battery from the device.
- 4) Make sure to Connect RED to positive Terminal of Battery. WHITE is Negative.