

# Elite D4-8 Amp Menu Tree

## PAGES

## PARAMETERS

## ENCODER KNOB

Act-Inst No Pad

MAIN MIX  
4 CH

Pass GL-Inst Pad  
Mic No Pad

MAIN PAN

MAIN OUT

CHEQ

LOW / MED / HI

CH UTILITIES

POLARITY  
NOTCH  
FILTER  
HI PASS

CH DYNAMICS

GATE  
COMPRESSOR

AUX MIX  
4 CH

AUX PAN  
AUX LEVEL

DELAY MIX  
INSERT CH  
LEVEL

LO FILTER  
REPEATS  
TIME X  
BPM

REVERB SEND  
4 CH

PRE-DELAY  
SHIMMER  
DECAY  
TONE

## SYSTEM

INPUT METERS  
CH 1-4

< 12 db  
CH 1-3 Inputs  
CH 1-3 Pad  
CH 4 Input

MEMORIES

1-10

ASSIGNS

A/B Footswitch

Memory Up / Dn

Channels  
1-2 / 3-4  
1-4 / Fx  
1/2  
Reverb / Delay

Main / Aux Mix

$\frac{1}{2}$  /  $\frac{1}{8}$

Main  
Aux  
Mix